


Running a Data logger code and building a Light_Classification project on NanoEdge AI Studio

Studio


Experiment Overview:

The goal of this experiment is to run a data logger, so as to build our machine learning model on NanoEdge AI Studio. After uploading our code on the target Microcontroller, we will create a project on NanoEdge AI Studio for classifying different light data samples. The developed model should be able to classify different types of Light data samples we provide during the training cycles.



Procedure (NanoEdge AI Studio):

1. Open NanoEdge AI Studio.
2. Select **n-Class Classification** project type and select **Create New Project**.






3. A new window will open. On the first step, **Project Settings**, name the project as Light Classification. Under **Description** type “Classifying irregularities in flashlight”.

Name	Light_Classification	20 / 40
Description	Classifying irregularities in flashlight	


4. Let **Max RAM** and **Max Flash** option remain as default.

Library Max RAM	
32	KB
Library Max Flash	
No Flash limit <input type="checkbox"/> Limit Flash	64 KB

5. In **Target** section, select your proper STM32 Nucleo board. In **Sensor type** section, select the type of sensor you are working with. For this experiment you have to choose **Generic 1-Axis**.

Overview	Commercial Part N° ↑	MCU Series	Link	Favorite	
<input checked="" type="checkbox"/>		NUCLEO-F411RE	STM32F411RET6		

Development libraries are available




Right of use on any STM32 for development purposes only


CANCEL CONFIRM



Warning: the sensor settings below may not be modified after the project settings are saved.

Sensor type	Number of axes
 Generic	1 Axis

6. Click on **Save & Next** to move onto the next step.



Project settings | Signals | Benchmark | Emulator | Validation | Deployment

NUCLEO-F411RE
32KB RAM
1 axis

3 Classes
1 Benchmark


Name: Light_Classification
Description: Classifying irregularities in flashlight
Library Max RAM: 32 KB
Library Max Flash: 64 KB
No Flash limit | Limit Flash
Your target: NUCLEO-F411RE

Warning: the sensor settings below may not be modified after the project settings are saved.

Sensor type: Generic
Number of axes: 1
Axis: Axis

SAVE & NEXT | DELETE PROJECT

7. In the second step on NanoEdge AI Studio – **Signals**, click on **Add Signals**. A window will open with different source options for you to import signals, select **From Serial (USB)** as we are collecting sensor data connected to microcontroller board, which in turn is connected to your PC through a Serial USB Cable.



ADD SIGNAL

Data format example:
n buffers of 256 values x 3 axes (x,y,z) with space separator

line 1: x_0 y_0 z_0 x_1 y_1 z_1 (...) x_{255} y_{255} z_{255}
line 2: x_0 y_0 z_0 x_1 y_1 z_1 (...) x_{255} y_{255} z_{255}
(...)
line n: x_0 y_0 z_0 x_1 y_1 z_1 (...) x_{255} y_{255} z_{255}


Best Practices:
- buffer size = power of 2
- minimum 20 lines (signal examples) per sensor axis





Import signal

1 Type of signal source 2 Signal 3 Preview

Select your signal source type

FROM FILE 

FROM SERIAL (USB) 

FROM FP-SNS-DATALOG 

CLOSE

8. Now you can add your signals. In **COM Port** select the correct COM port based on device manager info. Select **Baud rate** as 115200. In **Maximum number of lines** enter the number of lines of data you want to collect. In this case we will collect 200 lines of data.

Import signal

✓ Type of signal source 2 Signal 3 Preview

COM Port
COM8

Baudrate
115200

☒ Maximum number of lines
200


START/STOP

Number of lines: 5

Serial output

```
410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00 410.00
410.00 410.00 410.00 410.00 410.00 418.33 418.33 418.33 418.33 418.33 418.33 418.33 418.33 418.33 418.33 418.33
```


9. Before adding signals, download the flashlight application from **Google Play Store**.



10. To add signals, first turn on the flashlight and keep it to 0 and then click on **START/STOP**. Keep the flashlight to 0 until 200 lines of data are collected, then stop the process.



11. Click on **Continue** to move onto importing the light samples.



12. In this window, select the **Delimiter** as **Space**. If any line of data has some corrupted values, an error message will be shown under the preview lines. You can select the particular line(s) and delete it. Select **Preview Lines** as 200 to check all the line of data you have collected, and click on **Import**.

Import signal

☒ Type of signal source
 ☒ Signal ¹
☐ Preview ³

Delimiter

☐ Comma
 ☐ Tab
 ☐ Semicolon
 ☒ Space
 ☐ Other:

Enter delimiter

DELETE LINES

< Preview of 20 lines >


delete	line_index	nb_columns	1	2	3	4	5
<input type="checkbox"/>	1	256	455	455	455	455	455
<input type="checkbox"/>	2	256	429.17	429.17	429.17	429.17	429.17
<input type="checkbox"/>	3	256	428.33	428.33	428.33	428.33	428.33
<input type="checkbox"/>	4	256	452.5	452.5	452.5	452.5	452.5

PREVIOUS

Preview lines
 20

CLOSE


13. In the new window, rename the sample under **Name** as **Flashlight Working** and click on the blue save icon to save the renamed sample.



14. Now select **Add Signal** again and collect the samples for continuous flashlight. For continuous flashlight, keep it in 4. Now by using the same process as above, select Continue, select import, and name the file as **Flashlight_Not_Working**.



15. Now turn off the flashlight and do the same process as above and name the file as **No_Flashlight**.



The screenshot shows the DigiToad interface with the 'Signals' section active. The top navigation bar includes 'Project settings', 'Signals', 'Benchmark', and 'Emulator'. Below the navigation bar, the 'Signals' section displays '3 Classes' and '1 Benchmark'. The 'ADD SIGNAL' button is visible. A list of signals is shown, with 'No_Flashlight' highlighted in blue. The other signals are 'Flashlight_Not_Working' and 'Flashlight_Working'. The 'Name' field is set to 'No_Flashlight'. The 'DOWNLOAD SIGNAL FILE' button is visible. The file statistics are: Lines in file : 200, Number of values per line : 256, and Number of values per axis : 256.



Signal	Remove
No_Flashlight	X
Flashlight_Not_Working	X
Flashlight_Working	X

Name: No_Flashlight 13 / 30


DOWNLOAD SIGNAL FILE

Lines in file : 200
Number of values per line : 256
Number of values per axis : 256


16. In the third step of the Nano Edge AI Studio- **Benchmark**, click on **Run New Benchmark**. Next select **All classes** and click on **Start**. Now the Benchmark process will start and Nano Edge AI Studio will try to find the best library for your use case




17. After the Benchmark has reached a **Score** of above 90% stop the benchmark process.




18. After the benchmark process is done, go to the fourth stage, **Emulator**. Click on **Initialize Emulator** to move on to test the library you have selected on the Nano Edge AI Studio.





20. Finally go to **Deployment** stage, select **Float abi** and click on **Compile Library**. Click on **Get Library**, and save your library on the PC.



Note: All important steps and parts are highlighted with a red colour box for the proper understanding of the user. This document is meant for the use of education purpose only.